





Fischer Panda®

Power
wherever
you are™



Panda fpControl Manual

Current revision status

	Document
Current:	Panda_fpControl_eng.R01_27.5.20
Replaces:	

Revision	Page
	26/27

Created by

Fischer Panda GmbH - Head of Technical Documentation

Otto-Hahn-Str. 32-34

33104 Paderborn - Germany

Phone: +49 (0) 5254-9202-0

e-mail: info@fischerpanda.de

web: www.fischerpanda.de

Copyright

Reproduction of and changes to the manual are permitted only by agreement and with the permission of the manufacturer!

Fischer Panda GmbH, 33104 Paderborn, reserves all rights regarding text and graphics in this document. Details are given to the best of our knowledge. No liability is accepted for correctness. Please note: technical modifications aimed at improving the product may be implemented without prior notice. Therefore, it must be ensured prior to installation that the pictures, diagrams, and related material are applicable to the equipment supplied. In case of doubt, verify upon delivery that documentation and equipment match.



Fischer Panda GmbH
 Otto-Hahn-Str. 40
 D-33104 Paderborn
 Germany

Phone: : +49 (0)5254 9202-0
 Fax.: : +49 (0)5254 9202-550
 Hotline : +49 (0)5254 9202-767
 E-mail: : info@fischerpanda.de
 Web : www.fischerpanda.de



1.1 Download



Weitere verfügbare Sprachen dieses Handbuches können unter dem unten angegebenen Link heruntergeladen werden.



Other available languages of this manual can be downloaded under the link below.



Vous trouvez d'autres langues disponibles de ce manuel en suivant le lien ci-dessous:



Otros idiomas disponibles en este manual se pueden descargar en el link de abajo:



本手册的其他语言版本可从以下链接下载：

http://www.fischerpanda.de/gensetdocs_eng.htm

Table of Contents

Current revision status	2
1.1 Download	3
1 Panda fpControl Safety Instructions	7
1.1 Personnel.....	7
1.2 Safety instructions	7
1.3 Function description.....	20
1.4 Proper use	8
2 Panda fpControl	9
2.1 Components of the fpControl	9
2.1.1 fpControl - CP-G	9
2.1.1.1 Environmental specifications, physical data of the fpControl CP-G	9
2.1.2 fpControl - GC-S	10
2.1.2.1 Environmental specifications, physical data of the fpControl GC-S	10
2.1.3 fpControl - CB-G	10
2.1.3.1 fpControl CB-G connections	11
2.1.3.2 Environmental specifications, physical data of the fpControl CB-G	11
2.1.4 fpControl CAN Interface - SAE J1939 (fpControl CI-SAE J1939)	11
2.1.4.1 fpControl CI-SAE J1939 connections.....	12
2.1.4.2 Environmental specifications, physical data of the fpControl CI-SAE J1939 ...	12
2.1.4.3 fpControl Measurement Unit - MU-3ph/DC (fpControl MU-3ph/DC)	12
2.1.4.4 fpControl MU-3ph/DC connections	13
2.1.4.5 Environmental specifications, physical data of the fpControl MU-3ph/DC	13
2.1.5 fpControl Measurement Unit - MM-3 (fpControl MM-3)	13
2.1.5.1 Environmental specifications, physical data of the fpControl MM-3.....	14
2.2 Installation.....	14
2.2.1 Installation of the Electronic Control Unit (ECU) fpControl - GC-S	14
2.2.2 Installation of the Connection Box fpControl - CB-G	14
2.2.3 Installation of the fpControl - CP-G	14
2.3 Operation	15
2.3.1 Switching on the generator	15
2.3.1.1 Overview page with Autostart activated	16
2.3.2 The fpControl VCS overview pages	17
2.3.3 The fpControl AGT overview pages	20
2.3.3.1 Battery guard.....	22
2.3.3.2 Functional description of the UIU charging process.....	22
2.3.4 The fpControl Inverter overview pages	24
2.4 Starting up the generator.	28
2.4.1 Preparations for starting up / Checks (daily) for marine version	28
2.4.2 Preparations for starting up / Checks (daily) for vehicle version	28
2.4.3 Starting up the generator	29
2.4.4 Stopping the generator	30
2.5 The Menu.....	31
2.5.1 Main Menu	31
2.5.2 Sub-menu: "Panel"	31
2.5.2.1 Setting the illumination of the CP-G	32
2.5.2.2 Setting the contrast of the CP-G	32
2.5.2.3 Setting the standby time of the CP-G.....	33
2.5.2.4 Setting the standby illumination of the CP-G	33
2.5.2.5 Setting the display mode of the CP-G overview page.....	33
2.5.2.6 Setting the language of the text pages of the CP-G.....	33

Table of Contents

2.5.2.7	Setting the Temperature Unit	34
2.5.2.8	Setting the Aural Alarm	34
2.5.2.9	Setting the display to flash in the event of a fault	34
2.5.2.10	Setting the Panel Heating	35
2.5.2.11	Setting the display of the optional measurement data	35
2.5.2.12	Supplementary Start-up functions	35
2.5.2.13	Resetting all values of the Panel sub-menu to default values	36
2.5.2.14	Return to Main Menu	36
2.5.3	Sub-menu: "Generator"	36
2.5.3.1	Setting the Autostart of the CP-G	37
2.5.3.2	Setting the optional water pump/fan DC output of the CP-G	38
2.5.3.3	Switching the switching outputs of the CP-G	38
2.5.3.4	Reading out the Event Memory of the CP-G	38
2.5.3.5 Resetting all values of the Generator sub-menu to the default values	39
2.5.3.6	Returning the Main Menu	39
2.5.4	Resetting the panel language to the default (English)	39
2.5.4.1	How to set the panel language after a reset	39
2.6	Faults	40
2.6.1	Symbols and messages on the display	40
2.6.1.1	Example of message - "Sensor defective"	40
2.6.1.2	Example of message - "Sensor/Cable break"	40
2.6.2	Error code	40
2.6.2.1	Table of Faults	41
2.6.2.2	Description of the symbols	43
2.7	Accessories:	44
2.7.1	Dimensional drawing	46
3	Submenu: "Service"	47
3.1	To call up the Service menu	47
3.2	Service menu	48
3.2.1	Enter service code	49
3.2.2	Switching Outputs (S)	50
3.2.3	Boost time (for FP x generators only)	50
3.2.4	Boost voltage (for FP x generators only)	50
3.2.5	Control (for FP x generators only)	51
3.2.6	Control value	51
3.2.7	Service performed	51
3.2.8	Actuator Setup	52
3.2.9	Balance (PNL->MCU)	52
3.2.10	Parallel mode	52
3.2.11	Displaying system devices	52
3.2.12	Configuring the generator	53
3.2.13	Frequency (for FP i generators only)	53
3.2.14	Starter battery	53
3.2.15	Multifunc. outputs	54
3.2.16	Parameter Overview	54
3.2.17	Battery charger (for FP AGT generators only)	54
3.2.17.1	Functional description of the UIU charging process	55
3.2.18	Reset to standard	58
3.2.19	Back	58

1. Panda fpControl Safety Instructions

1.1 Personnel

The settings described here can be performed by the operator unless highlighted differently.

The installation should be implemented by specially trained technical personnel or by authorised workshops (Fischer Panda Service Points), only.

1.2 Safety instructions

Adhere to the safety instructions in the Fischer Panda generator manual.

Note!

If these instructions are not to hand, they can be requested from Fischer Panda GmbH, 33104 Paderborn, Germany.



An external signal may trigger an automatic start-up.

Warning! Automatic start-up



The generator must not be operated with the cover removed.

Warning!

If the generator is to be installed without a sound insulation capsule, it must be ensured that all rotating parts (belt pulley, belts etc.) are covered and protected so that there is no danger to life and body!



All service, maintenance, or repair work may only be carried out when the unit is not running.

Electric voltage - Deadly Danger!

Warning! Electrical voltage

Electric voltages of more than 48V are potentially lethal in any situation. The rules of the respective regional authority must be adhered to for installation and maintenance.



For safety reasons, only an electrician may carry out the installation of the electrical connections of the generator.

Disconnect battery before working on the generator

Attention!

The battery must always be disconnected (first the negative terminal, then the positive terminal) if work on the generator or electrical system is to be performed, so that the generator cannot be started inadvertently.



This applies in particular to systems with an automatic start-up function. The automatic start-up function shall be deactivated before starting work.

The flooding valve must be closed. (For PMS version only.)

Also observe the safety instructions for the other components of your system.

Note!



1.3 Function description

The fpControl system is intended for the operation, monitoring and control of piston-powered generators.

1.4 Proper use

Intended exclusively for use with Fischer Panda generators, the proper use of which arises from the declaration of conformity of the complete machine.

2. Panda fpControl

2.1 Components of the fpControl

2.1.1 fpControl - CP-G

(Control Panel – Generator)

Display and Control Element of the fpControl

The fpControl CP-G is the display and control element

Power is supplied via the bus cable. Multiple control elements can be installed in a single system.

Fig. 2.1.1-1: Control Panel - Generator



2.1.1.1 Environmental specifications, physical data of the fpControl CP-G

Storage temperature	-10 °C – +60 °C
Operating temperature	-20 °C – +50 °C
Supply voltage	12 V or 24 V, automotive (12–13,5 V or 24–28 V)
Rated current consumption	< 21 mA @ 12 V (without display heating) < 18 mA @ 24 V (without display heating)
Max. current consumption	120 mA (with display heating)
Current consumption in Standby mode / Off	0 A
Housing	ABS plastic
Protection class	IP30 (RJ45 plug plugged in)
Overall dimensions	120 x 65 x 35 mm (L x B x H), Cutout: 109,2 x 54,5 mm
Weight	0,11 kg
FP part number	0029338
Circuit board	FP1403

2.1.2 fpControl - GC-S

(Generator Control - Servo)

Main module of the fpControl.

The module contains the control electronics.

The fpControl GC-S is usually installed in the generator capsule.

The fpControl GC-S takes over the monitoring and control of the diesel engine of the Fischer Panda generator, as well as the control of the output voltage and frequency of the generator.

Fig. 2.1.2-1: Generator Control - Servo



The fpControl GC-S is suitable for 12 V and 24 V starting systems. The connected actuators are supplied with power via switching outputs with input voltage.

Current measurement is single-phase and can be done directly. A voltage sensor is not necessary. Current measurement takes place via an external current sensor. An additional three-phase module can be used for 3-phase generators.

2.1.2.1 Environmental specifications, physical data of the fpControl GC-S

Ambient temperature	-40 °C – +125 °C (max.)
Operating temperature	90 °C
Supply voltage	12 V or 24 V, automotive (12–13,5 V or 24–28 V)
Rated current consumption	< 66 mA @ 12 V < 77 mA @ 24 V
Housing	Automotive, PBT GF30
Protection class	IP65
Overall dimensions	117 mm x 136 mm (inkl. Stecker)
Weight	0,25 kg
FP part number	0029554
Circuit board	FP1704

2.1.3 fpControl - CB-G

(Connection Box - Generator)

The fpControl CB-G is usually installed in the generator capsule (externally).

The fpControl CB-G is the external terminal block for the fpControl generator.

The control element and the fuel pump are connected here. Emergency stop devices, auto-start devices, load relays and boosters can be connected as options.

Fig. 2.1.3-1: Connection Box - Generator



Only qualified electricians may perform work on the fpControl CB-G.

Note:



2.1.3.1 fpControl CB-G connections

1 x RJ45	Control Panel/fpCAN
1 x 2-pole Phoenix contact socket	Boost relay/Inverter power supply
1 x 2-pole Phoenix contact socket	Multifunction output 1 A)
1 x 2-pole Phoenix contact socket	Multifunction output 5 A)
1 x 2-pole Phoenix contact socket	Powerline relay
1 x 2-pole Phoenix contact socket	Automatic start-up contact
1 x 2-pole Phoenix contact socket	Emergency-stop
1 x 2-pole Phoenix contact socket	Fuel pump (5 A)
1 x 2-pole Phoenix contact socket	Water pump/Fan (5 A)
1 x 4-pole Phoenix contact socket	Alternative for the fpCAN
1 x 4-pole Phoenix contact socket	Boost relay Universal output 1 Universal output 2
1 x 12-pole Phoenix contact socket	Digital output - Water pump/Fan Digital output - Fuel pump Emergency-stop Automatic start-up contact Wake-up line CAN-High CAN-Low Bus voltage GND

2.1.3.2 Environmental specifications, physical data of the fpControl CB-G

Storage temperature	-40 °C – +125 °C
Operating temperature	-20 °C – +100 °C
Supply voltage	without own power supply
Rated current consumption	--
Housing	Plastic
Protection class	IP12
Overall dimensions	216,9 x 50,1 x 29,6 mm (L x B x H)
Weight	0,13 kg
FP part number	0000306
Circuit board	FP1801

2.1.4 fpControl CAN Interface - SAE J1939 (fpControl CI-SAE J1939)

The »fpControl CAN Interface - SAE J1939« manages the communication between the »fpCAN« and an external SAE J1939-CAN-BUS. The interface protects the the internal »fpCAN« by filtering the data of the external CAN-Bus. The internal and external CAN-Bus are galvanically isolated. The fpControl CI-SAE J1939 is supplied with power via the fpCAN.

Figure: »fpControl CAN Interface - SAE J1939« (fpControl CI-SAE J1939), Illustration shows an older hardware status

Fig. 2.1.4-1: fpControl CAN Interface - SAE J1939



2.1.4.1 fpControl CI-SAE J1939 connections

2 x RJ45	Power supply and internal fpCAN (FP CAN BUS 1)
2 x RJ45	external fpCAN (FP CAN BUS 2)
1 x 4-pole Phoenix contact socket	Alternative for the external fpCAN (USER CAN BUS)


2.1.4.2 Environmental specifications, physical data of the fpControl CI-SAE J1939

Storage temperature	-30 °C – +60 °C
Operating temperature	-20 °C – +50 °C
Supply voltage	12 V or 24 V, automotive (12–13,5 V or 24–28 V)
Rated current consumption	< 32 mA @ 12 V < 17 mA @ 24 V
Housing	ABS plastic
Protection class	IP30
Overall dimensions	151 x 80 x 60 mm (L x B x H)
Weight	0,25 kg
FP part number	0006107
Circuit board	FP1409

2.1.4.3 fpControl Measurement Unit - MU-3ph/DC (fpControl MU-3ph/DC)

The fpControl Measurement Unit - MU-3ph/DC« is used for AC and DC generators. On AC generators, the module measures the 3-phase AC voltage up to 400 V and three times the AC current by means of an external sensor. When used on DC generators, the module measures the 2-phase DC voltage in a range from 12 V to 600 V and twice the DC current by means of an external sensor.

Fig. 2.1.4-1: fpControl Measurement Unit - MU-3ph/DC



2.1.4.4 fpControl MU-3ph/DC connections

2 x RJ45	Power supply and fpCAN
1 x 4-pole Phoenix contact socket	Alternative for the external FP Bus (USER CAN BUS)
1 x 5-pole Phoenix contact socket	AC: Voltage measurement L1, L2, L3 and N (0 ... 400 V~ RMS) and PE or DC: 3 x (+), 1 x (-), 1 x PE (669 V DC)
1 x 3-pole Phoenix contact socket	external transformer L1
1 x 3-pole Phoenix contact socket	external transformer L2
1 x 3-pole Phoenix contact socket	external transformer L3
1 x 5-pole Phoenix contact socket	Voltage measurement (0 ... 69 V DC) 3 x (+), 1 x (-), 1 x PE
3 x 2-pole Phoenix contact socket	Temperature sensor
1 x 2-pole Phoenix contact socket	Boost
1 x 2-pole Phoenix contact socket	AUX

2.1.4.5 Environmental specifications, physical data of the fpControl MU-3ph/DC

Storage temperature	-30 °C – +60 °C
Operating temperature	-20 °C – +50 °C
Supply voltage	12 V or 24 V, automotive (12–13,5 V or 24–28 V)
Rated current consumption	< 139 mA @ 12 V < 91 mA @ 24 V
Housing	--
Protection class	IP30
Overall dimensions	114 mm x 72,5 mm (L x B) (circuit board)
Weight	0,094 kg (circuit board)
FP part number	0029859
Circuit board	FP1901

2.1.5 fpControl Measurement Unit - MM-3 (fpControl MM-3)

The »fpControl Measurement Unit - MU-MM-3/DC« is used for AC generators. The module measures the 3-phase AC voltage and three times the AC current. Current measurement is performed by the module directly by means of three internal current sensors. The measuring range is 65 A per phase. Higher currents can be measured by means of optional external current sensors.

Fig. 2.1.5-1: fpControl Measurement Unit - MM-3 (fpControl MM-3)

Figure: »fpControl Measurement Unit - MM-3« (fpControl MM-3) - Circuit board




Figure: »fpControl Measurement Unit - MM-3« (fpControl MM-3) in housing



fpControl MM-3 connections

2 x RJ45	Power supply and fpCAN
1 x 4-pole Phoenix contact socket	Alternative for the external FP Bus (USER CAN BUS)
1 x 3-pole Phoenix contact socket	external transformer N
1 x 3-pole Phoenix contact socket	external transformer L1
1 x 3-pole Phoenix contact socket	external transformer L2
1 x 3-pole Phoenix contact socket	external transformer L3
1 x 2-pole Phoenix contact socket	Voltage measurement / internal transformer L1, max. 65 A
1 x 2-pole Phoenix contact socket	Voltage measurement / internal transformer L2, max. 65 A
1 x 2-pole Phoenix contact socket	Voltage measurement / internal transformer L3, max. 65 A
2 x 1-pole Phoenix contact socket	N
1 x 1-pole Phoenix contact socket	PE

2.1.5.1 Environmental specifications, physical data of the fpControl MM-3

Storage temperature	-30 °C – +60 °C
Operating temperature	-20 °C – +50 °C
Supply voltage	12 V or 24 V, automotive (12–13,5 V or 24–28 V)
Rated current consumption	< 71 mA @ 12 V < 36 mA @ 24 V
Housing	ABS plastic
Protection class	IP30
Overall dimensions	151 x 80 x 60 mm (L x B x H)
Weight	0,212 kg (circuit board, fitted)
FP part number	0023600 (Circuit board FP1405 V7)
Circuit board	FP1405

2.2 Installation

2.2.1 Installation of the Electronic Control Unit (ECU) fpControl - GC-S

The ECU fpControl - GC-S is pre-installed. The ECU can be exchanged easily. All connections are mechanically coded and prevent the risk of confusion.

2.2.2 Installation of the Connection Box fpControl - CB-G

The connection box is pre-installed. External components are connected in accordance with the installation manual and the circuit diagram of the fpControl generator.

2.2.3 Installation of the fpControl - CP-G

The fpControl - CP-G is a CAN Bus module. All Fischer Panda CAN bus modules have two RJ45 ports. One for connection to the module on the CAN bus, the second to relay the CAN bus. The last module on the CAN bus must have a terminating resistor in the RJ45 port.

Connection by means of the Fischer Panda bus cable is mandatory.

Fig. 2.2-1: fpControl CP-G rear



Fig. 2.2-2: Connection Diagram

2.3 Operation

The fpControl is operated by means of the fpControl CP-G panel.

Fig. 2.3-1: fpControl CP-G front with buttons




2.3.1 Switching on the generator

Press the "ON/OFF" button to switch on the control system of the generator.

The fpControl Generator thereby switches to "Standby Mode".


If automatic starting is activated at the menu, the generator can henceforth be started by means of an external signal.

Fig. 2.3.1-1: Switching on the generator



The CP-G Panel displays the home page for two seconds.

Fig. 2.3.1-2: Home Page



The CP-G then displays the address page for one second.

Fig. 2.3.1-3: Address Page

```

addr.: 7
vers.: V5.02-RC1
serial: 0000001


---
addr.: 15
vers.: V0.02
serial: 1900301
preset: 2000
    
```

At the end of the power-on routine, the CP-G displays the first overview page.

The language as well as the display mode can be set in the menu.

Overview Page 1 is the same in all display modes/languages.

Fig. 2.3.1-4: Overview Page 1



2.3.1.1 Overview page with Autostart activated

Deadly danger! - The generator can be equipped with an Autostart function. This means that the generator is started by an external signal. In order to prevent an inadvertent start-up, the starter battery must be disconnected before work on the generator may commence.

Warning! Autostart



The "Autostart" also remains active, if the fpControl CP-G is switched off and on again.

If a fault should arise when the generator is started or is already operating, it is stopped and the Autostart is set to "off".


If the generator is operated by Autostart and is stopped manually, the Autostart is set to "off".

Once the system has been switched off and then on again, the Autostart is active once more.

The first overview page shows if the Autostart is active.


Overview Page 1 with Autostart function activated.

Fig. 2.3.1-1: Overview Page 1 with Autostart



2.3.2 The fpControl VCS overview pages


The display mode/language of the display can be set in the menu.



Overview Page 1:

- 01. Generator Status (on/off)
 - 02. AC OK
 - 03. Temperature of the generator (OK/Error)
 - 04. Operating hours of the generator
 - 05. Info screen
- Overview Page 1 is the same in all languages.


Fig. 2.3.2-1: Symbols used - Overview Page 1



Overview Page 2 (Generator):

- 06. Output voltage [V]
- 07. Generator current [A]
- 08. Generator apparent power [kVA]



Fig. 2.3.2-2: Overview Page 2 Symbols/English



Overview Page 3 (Generator):

- 09. Generator apparent power [kVA]
- 10. Power Factor

Fig. 2.3.2-3: Overview Page 2 Symbols/English

09		2.5kVA	✓
10		1.00	mm

09	power (S)	2.5kVA	✓
10	power-factor	1.00	mm




In the case of 3-phase generators, the voltage, the current and the electrical power are shown on separate pages. Each page shows the value of one of the three phases one below the other.

Example of the voltage display of a 3-phase generator.

Note:



Fig. 2.3.2-4: Voltage display 3-P Symbols/English/




06		231V	✓
07		11A	✓
08		2.5kW	✓

06	voltage L1-N	231V	✓
07	current L1	11A	✓
08	power (P) L1	2.5kW	✓

Overview Page 4:

- 09. Frequency of the generator [Hz]
- 10. Generator speed (r.p.m.)
- 11. Voltage of the starter battery [V]

Fig. 2.3.2-5: Overview Page 3 Symbols/English







09		0.0Hz	✓
10		0rpm	✓
11		13.2V	✓

09	frequency	0.0Hz	✓
10	rotational speed	0rpm	✓
11	bat.-volt.	13.1V	✓

Overview Page 4:

- 12. Temperature of the cylinder head
- 13. Temperature of the generator winding
- 14. Temperature at exhaust manifold

Fig. 2.3.2-6: Overview Page 4 Symbols/English

12			---°C	X	↑
13			---°C	X	
14			---°C	X	
12	engine temperature		62°C	✓	↑
13	winding temperature		60°C	✓	
14	exhaust temperature		58°C	✓	

If the information pages of optional components (e.g. fuel gauge, oil pressure) are available, then these pages are inserted after Overview Page 4.

Whether these pages are displayed automatically, always or not at all can be set in the Panel menu.

Final Overview Page:

Proceed to this menu by pressing the Start/Stop - Enter key
Overview Page 5 is the same in all display modes/languages.

Note:



Fig. 2.3.2-7: Final overview page



2.3.3 The fpControl AGT overview pages


The display mode/language of the display can be set in the menu.

The battery-specific charging parameters are set by the Fischer Panda Service Point.

When exchanging a battery this must be checked and adjusted accordingly.

Incorrect setting of the charging parameters may result in the battery being damaged or destroyed. The specifications of the battery manufacturer must be adhered to.

Warning:




Overview Page 1:

- 01. Generator Status (on/off)
- 02. AC OK
- 03. Temperature of the generator (OK/Error)
- 04. Operating hours of the generator
- 05. Info screen

Overview Page 1 is the same in all languages.


Fig. 2.3-1: Symbols used - Overview Page 1



Overview Page 2:

- 11. DC voltage [V]
- 12. DC current [A]
- 13. DC output [kW]




Fig. 2.3.3-2: Overview Page 2 Symbols/English



Overview Page 3:

- 14. Temperature of the diode plate fan
- 15. Temperature of the diode plate busbar (-)
- 16. Temperature of the diode plate busbar (+)




Fig. 2.3.3-3: Overview Page 3 Symbols/English

14		23°C	✓	↑
15		20°C	✓	
16		18°C	✓	
14	B6 cooler	23°C	✓	↑
15	B6 rail (-)	20°C	✓	
16	B6 rail (+)	18°C	✓	

Overview Page 4:

- 06. Frequency of the generator [Hz]
- 07. Generator speed (r.p.m.)
- 08. Voltage of the starter battery [V]




Fig. 2.3.3-4: Overview Page 4 Symbols/English

06		0.0Hz	✓	↑
07		0rpm	✓	
08		13.2V	✓	
06	frequency	0.0Hz	✓	↑
07	rotational speed	0rpm	✓	
08	bat.-volt.	13.1V	✓	

Overview Page 5:

- 09. Temperature of the cylinder head
- 10. Temperature of the generator winding
- 11. Temperature at exhaust manifold

Fig. 2.3.3-5: Overview Page 5 Symbols/English

09		---°C	✗	↑
10		---°C	✗	
11		---°C	✗	
09	engine temperature	---°C	✗	↑
10	winding temperature	---°C	✗	
11	exhaust temperature	---°C	✗	

If the information pages of optional components (e.g. fuel gauge, oil pressure) are available, then these pages are inserted after Overview Page 4.

Whether these pages are displayed automatically, always or

Note:



not at all can be set in the Panel menu.

Final Overview Page:

Fig. 2.3.3-6: Final overview page

Proceed to this menu by pressing the Start/Stop - Enter key
 Overview Page 5 is the same in all display modes/languages.



2.3.3.1 Battery guard


Generator must be in Standby mode (remote control panel switched on; generator off)

When the battery monitor is activated in the Service menu, the generator starts automatically as soon as the connected battery bank has reached the set minimum voltage. After the charging process (UIU) has ended, the generator switches off (back to Standby).

Activation of the battery monitor as well as the storage of individual parameters for UIU charging/the connected battery bank are performed by your Fischer Panda Service Point.

2.3.3.2 Functional description of the UIU charging process

Fig. 2.3.3.2-1: UIU charging curve of AGT-DC generator with FP Control



The UIU charging process: **linearly increasing voltage – constant current – constant voltage**

When the battery voltage has reached its minimal value U_{min} when discharging, the battery charger starts automatically, if the battery guard is activated. The UIU charging process begins:

Phase »Limit U«:	In the first phase, charging takes place with linearly increasing voltage This phase continues until the charging current has reached its maximum value I_{max} .
Phase »Limit I«:	In the second phase, charging takes place at constant current . In this phase, the maximum charging current I_{max} flows to the battery.
Phase »Limit U«	In the third phase, charging takes place at constant voltage U_n (absorption voltage). During this phase, the charging current drops to its minimum value I_{min} .
Phase »T«	Once the charging current has reached its minimum value I_{min} , the battery voltage is maintained at the U_n (absorption voltage) value throughout a hysteresis time T . The charging current continues to decrease during hysteresis.
Phase »Limit Ufloat«	After hysteresis the battery charger switches from loading at constant voltage U_n to float voltage U_{float} , thus ensuring that the fully charged condition of the battery is maintained throughout T_{float} .

Once the float time T_{float} has elapsed, the generator stops automatically.

Parameters of the charging curve

Parameter	Meaning	Corresponding menu item in "battery charger"
U_{\min}	Battery voltage at which the battery charging generator is started automatically.	min. voltage [V]
U_n	Constant charging voltage (absorption voltage), until the charging current has dropped to the minimum value I_{\min} .	absorption-voltage [V]
U_{float}	Once the battery has been charged, the float voltage ensures that the fully charged condition of the battery is maintained throughout the float time T_{float} .	float-voltage [V]
I_{\min}	If the minimum charging current is not achieved, the battery is fully charged. At this point in time, hysteresis T begins and continues until switching to the float voltage U_{float} .	min. current [A]
I_{\max}	Maximum charging current flowing to the battery.	max. current [A]
T	Once this time has elapsed, the system switches over to the float voltage U_{float} .	hysteresis [ms]
	"On" – Battery guard is activated, automatic generator start/stop is active. The generator is started automatically if the battery voltage drops below the minimum U_{\min} . "Off" – Battery guard is deactivated, automatic generator start/stop is deactivated.	battery guard [On/Off]
T_{float}	Once the float time has elapsed, the generator is stopped automatically if the battery guard is activated.	float-timeout [min]


The graphic display of the UIU charging curve displays the basic principle and symbolises the functionality.

NOTE:



2.3.4 The fpControl Inverter overview pages


The display mode/language of the display can be set in the menu.



Overview Page 1:

- 01. Generator Status (on/off)
 - 02. AC OK
 - 03. Temperature of the generator (OK/Error)
 - 04. Operating hours of the generator
 - 05. Info screen
- Overview Page 1 is the same in all languages.


Fig. 2.3.4-1: Symbols used in Overview Page 1



Overview Page 2 (Generator):

- 06. Output voltage [V]
- 07. Generator current [A]
- 08. Generator apparent power [kVA]



Fig. 2.3.4-2: Overview Page 2 Symbols/English



Overview Page 3:

- 09. Generator apparent power [kVA]
- 10. Power Factor

Fig. 2.3.4-3: Overview Page 3 Symbols/English

09		2.5kVA	✓	↑
10		1.00	mm	
11				↓
09	power (S)	2.5kVA	✓	↑
10	power-factor	1.00	mm	
11				↓




In the case of 3-phase generators, the voltage, the current and the electrical power are shown on separate pages. Each page shows the value of one of the three phases one below the other.

Note:



Example of the voltage display of a 3-phase generator.




Fig. 2.3.4-4: Voltage display 3-P Symbols/English/

06		231V	✓	↑
07		11A	✓	
08		2.5kW	✓	↓
06	voltage L1-N	231V	✓	↑
07	current L1	11A	✓	
08	power (P) L1	2.5kW	✓	↓

Overview Page 3:

- 09. Phase/Phase voltage
- 10. Generator apparent power [kVA]
- 11. Power Factor




Fig. 2.3.4-5: Overview Page 3 Symbols/English

09		398V	✓	↑
10		2.5kVA	✓	
11		1.00	mm	↓
09	voltage L3-L1	398V	✓	↑
10	power (S) L3	2.5kVA	✓	
11	power-L3 factor	1.00	mm	↓

Overview Page 4:

- 09. Frequency of the generator [Hz]
- 10. Generator speed (r.p.m.)
- 11. Voltage of the starter battery [V]




Fig. 2.3.4-6: Overview Page 4 Symbols/English

09		0.0Hz	✓	↑
10		0rpm	✓	
11		13.2V	✓	↓
09	frequency	0.0Hz	✓	
10	rotational speed	0rpm	✓	↓
11	bat.-volt.	13.1V	✓	

Overview Page 5:

- 12. Temperature of the cylinder head
- 13. Temperature of the generator winding
- 14. Temperature at exhaust manifold




Fig. 2.3.4-7: Overview Page 5 Symbols/English

12		---°C	✗	↑
13		---°C	✗	
14		---°C	✗	↓
12	engine temperature	62°C	✓	
13	winding temperature	60°C	✓	↓
14	exhaust temperature	58°C	✓	

Overview Page 6:

- 15. Inverter Temperature L1
- 16. Inverter Temperature L2
- 17. Inverter Temperature L3

Fig. 2.3.4-8: Overview Page 6 Symbols/English

15		20°C	✓	↑
16		19°C	✓	
17		18°C	✓	↓
15	engine temperature	62°C	✓	
16	winding temperature	60°C	✓	↓
17	exhaust temperature	58°C	✓	

If the information pages of optional components (e.g. fuel gauge, oil pressure) are available, then these pages are inserted after Overview Page 4.

Whether these pages are displayed automatically, always or

Note:



not at all can be set in the Panel menu.

Final Overview Page:

Proceed to this menu by pressing the Start/Stop - Enter key
Overview Page 5 is the same in all display modes/languages.

Fig. 2.3.4-9: Final overview page



2.4 Starting up the generator.

2.4.1 Preparations for starting up / Checks (daily) for marine version

1. Oil level check (ideal level: 2/3 Max).

The level should be about 2/3 of the maximum level when the engine is cold.

Furthermore, if installed, the oil level of the oil-cooled bearing must be checked before each start - see sight glass on generator front cover!.

2. Check cooling water level.

The external expansion tank should be filled to 1/3 in a cold state. It is very important that there is sufficient volume for expansion of the coolant.

3. Check if the raw water intake valve is open.

For safety reasons, the raw water intake valve must be shut after the generator has been switched off. It should be re-opened before starting the generator.

4. Check raw water filter.

The raw water filter must be regularly checked and cleaned. If the raw water intake is restricted by detached residue, this increases wear on the impeller.

5. Visual inspection

Control fixing bolts, check hose connectors for leaks, check electrical connections. Check electrical lines for damage/chafing.

6. Switch off loads.

The generator should only be started without a load.

7. Open fuel valve, if installed.

8. Close main battery switch (switch on).

2.4.2 Preparations for starting up / Checks (daily) for vehicle version

1. Oil level check (ideal level: 2/3 Max).

The level should be about 2/3 of the maximum level when the engine is cold.

Furthermore, if installed, the oil level of the oil-cooled bearing must be checked before each start - see sight glass on generator front cover!.

2. Check cooling water level.

The external expansion tank should be at 1/3 in a cold state. It is very important that there is sufficient volume available for expansion of the coolant.

3. Visual inspection

Control fixing bolts, check hose connectors for leaks, check electrical connections. Check electrical lines for damage/chafing.

4. Switch off loads.

The generator should only be started without a load.

5. Open fuel valve, if installed.

6. Close main battery switch (switch on).

7. Open the raw water intake valve (only in the case of Fischer Panda Marine generators)

2.4.3 Starting up the generator

Deadly danger! - The generator can be equipped with an Autostart function. This means that the generator is started by an external signal. In order to prevent an inadvertent start-up, the starter battery must be disconnected before work on the generator may commence.

Warning! Automatic start-up



1. Switch on the fpControl CP-G

The remote control panel is started by pressing the On/Off button. The On/Off button must be pressed until the Home page is displayed.

Fig. 2.4.3-1: Switch on the panel



2. Press the Start/Stop - Enter key


Fig. 2.4.3-2: Start the generator.



3. The fpControl preheats the diesel engine.

After preheating, the generator is started by the fpControl system.


Fig. 2.4.3-3: Preheating



4. Starter on.

In order to minimise current consumption, preheating is interrupted briefly when the starter is operated.


Fig. 2.4.3-4: Electric starter



5. Starter and preheater


As soon as the high inrush current of the starter has dropped, preheating is switched on again.

Fig. 2.4.3-5: Preheating




The engine idles for the first few seconds. Thereafter, the fpControl increases the speed to the operating speed and indicates this in the display.

Fig. 2.4.3-6: Increase revolutions



As soon as the AC voltage is within limits (e.g. 207 V-253 V at 230 V) (normal operating mode), the consumer can be connected.

Fig. 2.4.3-7: AC OK



Close the raw water intake valve in the event start-up problems (Panda Marine generators only)

ATTENTION:



If multiple attempts to start up are required (e.g. to bleed the fuel lines), then the raw water intake valve must definitely be shut while the attempts are being made. The cooling water impeller turns during the starting process and feeds cooling water. As long as the engine has not started up, the exhaust gas pressure is insufficient to discharge the coolant water that has been introduced. This protracted start-up process would flood the exhaust system with water. This can damage/destroy the generator/engine.

Re-open the raw water intake valve as soon as the generator has started.

2.4.4 Stopping the generator

1. Switch off loads.
2. Recommendation: With turbo engines and under a load that exceeds 70 % of the rated output, allow the generator temperature to stabilise for at least 5 minutes with load switched off.

At higher ambient temperatures (greater than 25 °C) the generator should always run for at least 5 minutes without load before it is switched off, regardless of the load having been switched off.

3. Press "Start/Stop" button (to switch off).

Fig. 2.4.4-1: Stopping



NOTE: Never switch off the main battery until the generator has stopped, shut the fuel valve if necessary!

ATTENTION:



4. Close the raw water intake valve (only in the case of Fischer Panda Marine generators)

2.5 The Menu

The menu can be accessed from the final overview page.
Switch on the CP-G and scroll down to "Enter Menu" page.
Press the Start/Stop - Enter key to enter the menu.

Fig. 2.5-1: Menu entry symbols



2.5.1 Main Menu

You can choose from the following sub-menus in the main menu:

Fig. 2.5.1-1: Main Menu

```
panel
generator
service
back
```

1. "Panel" sub-menu - The display of the of the panel can be adapted in the "Panel" sub-menu (e.g. brightness, language, etc.).
2. "Generator" sub-menu - All settings related to the generator can be made in the "Generator" sub-menu, e.g. bleeding the fuel pump etc.
3. The "Service" sub-menu is blocked and can only be accessed by trained personnel and Fischer Panda employees.
4. Back - back to the overview pages

2.5.2 Sub-menu: "Panel"

The following items can be selected in the Panel sub-menu:

Fig. 2.5.2-1: Sub-menu: Panel

1. Lighting
 - changes the brightness of the display in Normal mode.
2. Contrast
 - changes the contrast of the display.
3. Standby Time
 - to set the time until the panel switches to Standby mode.
4. Standby Lighting
 - changes the brightness of the display in Standby mode.
5. Display Mode
 - changes the display mode of the overview pages.
6. Language selection
 - changes the language of the panel
7. Temperature Unit

```
brightness
contrast
standby-timeout
standby-brightness
way of illustration
choose language
temperature unit

blink on error
panel-heater
opt. measured data
add. start function
update
reset to standard
back
```

- to set the temperature unit to °C or °F
- 8. Audible alarm
 - to activate the audible alarm in the event of faults
- 9. Flashing when faulty
 - to activate panel flashing in the event of faults
- 10. Panel heating
 - to activate panel heating at temperatures <+10°C
- 11. Optional measurement data
 - to manage the additional information pages, e.g. tank display
- 12. Additional start-up functions (only in the case of inverter generators)
 - Start without inverter/Inverter Softstart
- 13. Update
 - Software update for the panel
- 14. Reset to standard
 - to reset the "Panel" sub-menu to the factory settings
- 15. back
 - Switching from the "Panel" sub-menu to the Main Menu

2.5.2.1 Setting the illumination of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

The value is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.1-1: Sub-menu: Illumination

```

brightness
-----
minimum value      0 %
value              75 %
maximum value     100 %

cancel
confirm
  
```

2.5.2.2 Setting the contrast of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

The value is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.2-1: Sub-menu: Contrast

```

contrast
-----
minimum value      0 %
value              25 %
maximum value     100 %

cancel
confirm
  
```


2.5.2.3 Setting the standby time of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

The value is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.3-1: Sub-menu: Standby Time

```
standby-timeout
-----
minimum value      1 min
value              10 min
maximum value      60 min

cancel
confirm
```

2.5.2.4 Setting the standby illumination of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

The value is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop - Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop - Enter" key.

Fig. 2.5.2.4-1: Sub-menu: Standby Illumination

```
brightness
-----
minimum value      0 %
value              75 %
maximum value      100 %

cancel
confirm
```

2.5.2.5 Setting the display mode of the CP-G overview page

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Symbolic View" or "Text View" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

The "back" item returns you to the "Panel" sub-menu.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.5-1: Sub-menu: Display Mode

```
symbolic view
>text-view
back

cancel
confirm
```

2.5.2.6 Setting the language of the text pages of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

Select the corresponding language by using the "Step-up"/"Step-down" keys and then confirm with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.6-1: Sub-menu: Language Selection

```
deutsch
>english
中文
español
français
back

cancel
confirm
```

2.5.2.7 Setting the Temperature Unit

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"°C" for "degrees Celsius" or "°F" for "degrees Fahrenheit" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop - Enter" key.

The "Back" item returns you to the Panel sub-menu.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop - Enter" key.

Fig. 2.5.2.7-1: Sub-menu: Temperature Unit

```
>°C
°F
back

cancel
confirm
```

2.5.2.8 Setting the Aural Alarm

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Off" or "On" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

The "Back" item returns you to the Panel sub-menu.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.8-1: Sub-menu: Aural Alarm

```
off
>on
back

cancel
confirm
```

2.5.2.9 Setting the display to flash in the event of a fault

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Off" or "Error" or "Warning and Error" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

The "Back" item returns you to the Panel sub-menu.
 "Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.9-1: Sub-menu: Flashing when Faulty

```
>off
Errors
warnings & errors
back
```

```
cancel
confirm
```

2.5.2.10 Setting the Panel Heating

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Off" or "On" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

The "Back" item returns you to the Panel sub-menu.
 "Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.10-1: Sub-menu: Panel Heating

```
>off
on
back
```

```
cancel
confirm
```

2.5.2.11 Setting the display of the optional measurement data

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

The desired optional measurement data is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

The desired option is selected by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

The "Back" item returns you to the Panel sub-menu.
 "Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.11-1: Sub-menu: Optional Measurement Data

```
generator L I
3 phases
extra phase-data
fuel-level
oil-/air-pressure
inverter
back
```

```
cancel
confirm
```

2.5.2.12 Supplementary Start-up functions

This menu item is only available in the case of inverter generators

Fig. 2.5.2.12-1: Note



The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

The desired option is selected by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

The "Back" item returns you to the Panel sub-menu.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.12-2: Sub-menu: Supplementary Start-up functions

```
no function
>start w/o inverter
inverter softstart
back
```

```
cancel
confirm
```

2.5.2.13 Resetting all values of the Panel sub-menu to default values

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.2.13-1: Resetting all values

```
cancel
confirm
```

2.5.2.14 Return to Main Menu

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

2.5.3 Sub-menu: "Generator"

The following items can be selected in the Generator sub-menu:

1. Autostart
 - configuring the Autostart function
2. Water pump/Fan
 - setting the optional DC outputs
3. Switch Outputs
 - manual switching of the individual digital outputs
4. Event Memory
 - displaying the event memory
5. Display System Devices
 - displaying the detected system devices
6. Service performed
 - resets the service interval
7. Reset to standard
 - all parameters of the "Generator" sub-menu are reset to the factory settings
8. back
 - Switching from the "Generator" sub-menu to the Main Menu

Fig. 2.5.3-1: Generator Sub-Menu

```
autostart
waterpump/fan
switch outputs
event-log
show system-devices
service done
reset to standard
```

2.5.3.1 Setting the Autostart of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

A choice can be made between "Switch on/off" and "Number of start-up attempts" in the "Autostart" sub-menu.

Fig. 2.5.3.1-1: Autostart

```
turn on / off
amount of restarts
back
```

Switching On / Off

"Off" for deactivated or "On" for activated can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.3.1-2: Autostart

```
>off
on
back
```

Number of start-up attempts

The value is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

For safety reasons, the number of start-up attempts is limited to one in the case of marine (PMS) generators.

Fig. 2.5.3.1-3: Autostart

```
amount of restarts
-----
minimum value      :
value              :
maximum value      $
cancel
confirm
```

Deadly danger! - The generator can be equipped with an Autostart function. This means that the generator is started by an external signal. In order to prevent an inadvertent start-up, the starter battery must be disconnected before work on the generator may commence.

Warning! Automatic start-up.



The "Autostart" also remains active if the fpControl CP-G is switched off and then on again.


If a fault should arise when the generator is started or is already operating, it is stopped and the Autostart is set to "off".

If the generator is operated by Autostart and is stopped manually, the Autostart is set to "off".

Once the system has been switched off and then on again, the Autostart is active once more.

The first overview page shows if the Autostart is active.

Fig. 2.5.3-4: Overview Page 1 with Autostart



2.5.3.2 Setting the optional water pump/fan DC output of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Operating Mode" or "Follow-up Time" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

The "Back" item returns you to the "Generator" sub-menu.

Select "cancel" or "confirm" by using the "Step-up"/"Step-down" keys and then confirm with the "Start/Stop-Enter" key.

Setting the "Operating mode" for the optional DC output (DP) of the CP-G

An option can be selected by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Setting the follow-up time of the optional DP Output of the CP-G

The value is changed by using the "Step-up"/"Step-down" keys and the setting is confirmed with the "Start/Stop-Enter" key.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.3.2-1: Sub-menu: Optional DC Output

```
operating mode
follow-up time
back
```

Fig. 2.5.3.2-2: Sub-menu: Operating Mode

```
>depending on temp.
back
```

```
cancel
confirm
```

Fig. 2.5.3.2-3: Sub-menu: Follow-up Time

```
follow-up time
-----
minimum value      0.0 s
value              0.0 s
maximum value      0.0 s

cancel
confirm
```

2.5.3.3 Switching the switching outputs of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

Select "Fuel Pump" or "Opt. DC Outputs" by using the "Step-up"/"Step-down" keys and then confirm with the "Start/Stop-Enter" key.

The "Back" item returns you to the "Generator" sub-menu.

The value of the output can be set to "0" for deactivated or "1" for activated by using the "Step-up"/"Step-down" keys. Confirm with the "Start/Stop-Enter" key.

Fig. 2.5.3.3-1: Sub-menu: Switching Outputs

```
0 f.-pump
0 w.pump/fan

back

cancel
confirm
```

2.5.3.4 Reading out the Event Memory of the CP-G

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

Siehe "Table of Faults" auf Seite 41. Siehe "Description of the symbols" auf Seite 43.

Fig. 2.5.3.4-1: Event Memory



One can scroll through the event memory by using the "Step-up"/"Step-down" keys and then return to the Generator menu with the "Start/Stop-Enter" key.

By using the QR Code, the relevant fault page of the knowledgebase.fischerpanda.de can be called up via the Internet.

Note

To do so, simply scan the QR Code with a smartphone (Internet connection required).



2.5.3.5 Resetting all values of the Generator sub-menu to the default values

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

"Cancel" or "Confirm" can be selected by using the "Step-up"/"Step-down" keys and then confirmed with the "Start/Stop-Enter" key.

Fig. 2.5.3.5-1: Resetting all values



The screenshot shows a menu with two options: "cancel" and "confirm". The "cancel" option is highlighted with a black bar.

2.5.3.6 Returning the Main Menu

The menu item is selected by using the "Step-up"/"Step-down" keys and confirmed with the "Start/Stop-Enter" key. The respective menu item opens.

2.5.4 Resetting the panel language to the default (English)

1. Press and hold the "Step down" key with the panel switched off.
2. Switch on the panel and hold down the "Step down" key until the first overview screen is displayed.
3. The panel language has now been reset. All other settings are retained.

2.5.4.1 How to set the panel language after a reset.

1. Switch on the fpControl Panel CP-G
2. Wait until the first overview screen appears.
3. Scroll to the last overview screen.
4. Press the "Start/Stop-Enter" key to access the menu.
5. Scroll down to the "Panel" menu item.
6. Press the "Start/Stop-Enter" key to access the "Panel" sub-menu.
7. Scroll down to the "Choose language" menu item.
8. Press the Start/Stop-Enter key to access the "Language Selection" sub-menu.
9. Scroll to the desired language and confirm with the "Start/Stop-Enter" key.
10. Scroll down to the "confirm" menu item and press the "Start/Stop-Enter" key.

The menu text is now set to the selected language.

2.6 Faults








2.6.1 Symbols and messages on the display

2.6.1.1 Example of message - "Sensor defective"

As soon as a defective sensor is detected, the fpControl reports this on the display.



Fig. 2.6.1.1-1: Sensor defective







		26°C	✓
		---°C	
		25°C	✓

2.6.1.2 Example of message - "Sensor/Cable break"

If the sensor has failed or the cable is broken, the following report is displayed:



Fig. 2.6.1.2-1: Sensor/Cable break

		24°C	✓
		---°C	X
		23°C	✓




2.6.2 Error code

An error code is displayed if a parameter lies beyond its operating limits.

Siehe "Table of Faults" auf Seite 41. Siehe "Description of the symbols" auf Seite 43.

Example: Error No. 7 - Oil pressure too low -Fault led to emergency shutdown

Fig. 2.6.2.0-1: Sub-menu: "Event Memory"

Error type (Warning/Error shutdown)			Error symbol/ Error text
QR Code			
Error number	#00007		

(↓) - ✓

By using the QR Code, the relevant fault page of the knowledgebase.fischerpanda.de can be called up via the Internet.

Note



To do so, simply scan the QR Code with a smartphone (Internet connection required).

2.6.2.1 Table of Faults

See also the "Faults" chapter in the manual of the generator.

The relevant fault page of the knowledgebase.fischerpanda.de can be called up via the Internet.

Note



(Internet connection required).

Fig. 2.6-1: Table of faults





















No.	Description	Basic
1	AC Voltage L1	AC Voltage L1 is below its lower limit
2	AC Frequency L1	AC Frequency L1 is below its lower limit
5	Emergency-Off	Emergency-off switch is active/has been pressed
7	Oil pressure	Engine oil pressure is below its lower limit
8	Cylinder head temperature	Cylinder head temperature sensor not available/Contact open/Cable break
9	Winding temperature	Winding temperature sensor not available/Contact open/Cable break
10	Exhaust temperature	Exhaust temperature sensor not available/Contact open/Cable break
11	Electronics temperature	Temperature sensor for the electronic system (sensor on the fpControl circuit board) not available/defective
13	Starter motor current	Starter motor not connected/Starter motor defective
14	Glow plug circuit	One or more glow plugs not connected or defective
16	Fuel supply	Fuel valve/fuel pump not connected or defective
17	ETR Stop Solenoid hold	Current at output of the ETR hold coil is below the lower limit
18	ETR Stop Solenoid pull	Current at output of the ETR pull coil is below the lower limit
19	Water pump/Fan	Fan/water pump not connected or defective
20	Current sensor	Current sensor not available/Contact open/Cable break
21	Boost relay current	Boost relay not connected or defective
25	Starter battery voltage	Starter battery voltage too low
26	Engine speed error	Engine speed (r.p.m.) too low
30	AC Voltage L2	AC Voltage L2 is below its lower limit
31	AC Frequency L2	AC Frequency L2 is below its lower limit
34	AC Voltage L3	AC Voltage L3 is below its lower limit
35	AC Frequency L3	AC Frequency L3 is below its lower limit
38	Inverter DC supply	Current at output of the DC supply voltage of the inverter is below the lower limit
39	Universal output 1 (1A)	Electrical load on Universal output 1 is defective/no consumer connected
40	Universal output 2 (5A)	Electrical load on Universal output 2 is defective/no consumer connected
41	AGT DC voltage 1	Battery voltage too low
42	AGT DC current 1	Battery current too low
43	AGT DC voltage 2	Total voltage compared to battery voltage too low
44	AGT DC current 2	Sum of battery and load current too low
45	AGT B6 radiator	Temperature sensor not available/Contact open/Cable break
46	AGT B6 busbar (-)	Temperature sensor not available/Contact open/Cable break
47	AGT B6 busbar (+)	Temperature sensor not available/Contact open/Cable break
62	Fuel temperature	Temperature sensor not available/Contact open/Cable break
63	Fuel level	The fuel level has reached its lower limit
65	AC Voltage L1	AC Voltage L1 is above upper limit
66	AC Frequency L1	AC Frequency L1 is above upper limit
67	AC Current L1	AC Current L1 is above upper limit
68	AC Output L1	AC Output L1 is above upper limit
70	Servomotor current	Servomotor current is above upper limit









No.	Description	Basic
71	Oil pressure	Oil pressure is above upper limit
72	Cylinder head temperature	Temperature of the diesel engine / Cylinder head is above upper limit
73	Winding temperature	Winding temperature is above upper limit
74	Exhaust temperature	Exhaust temperature is above upper limit
75	Electronics temperature	Temperature of electronic system above upper limit
77	Starter motor output	Current at output of starter motor is above upper limit
78	Glow plug circuit	Current at output of the glow plugs is above upper limit
79	Flame-start system	Current at output of flame-start system is above upper limit
80	Fuel supply	Current at output of the fuel valve / fuel pump / DC generator exciter is above upper limit
81	Stop Solenoid hold	Current at output of the hold coil of the stop solenoid is above upper limit
82	Stop Solenoid pull	Current at output of the pull coil of the stop solenoid is above upper limit
83	Water pump/Fan	Current at output of the water pump/fan is above upper limit
84	Current sensor supply	Current at output of the current sensor is above upper limit
85	Boost relay	Boost relay fault
86	Bus current	Current at the CAN bus is above upper limit
89	Starter battery voltage	Starter battery voltage is above upper limit
93	Power output relay	Current at output of load-breaking relay is above upper limit
94	AC Voltage L2	AC Voltage L2 is above upper limit
95	AC Frequency L2	AC Frequency L2 is above upper limit
96	AC Current L2	AC Current L2 is above upper limit
97	AC Output L2	AC Output L2 is above upper limit
98	AC Voltage L3	AC Voltage L3 is above upper limit
99	AC Frequency L3	AC Frequency L3 is above upper limit
100	AC Current L3	AC Current L3 is above upper limit
101	AC Output L3	AC Output L3 is above upper limit
102	Inverter DC supply	Current at output of the DC supply of the inverter is above the upper limit
103	Universal Output 1 (1A)	Current at Universal Output 1 is above upper limit
104	Universal Output 2 (5A)	Current at Universal Output 2 is above upper limit
105	AGT DC Voltage 1	Battery voltage too high
106	AGT DC Current 1	Battery current too high
107	AGT DC Voltage 2	Total voltage compared to battery voltage too high
108	AGT DC Current 2	Sum of battery and load current too high
109	AGT B6 Radiator	Temperature at heat sink of the B6 bridge too high/Sensor error: Short circuit on temperature sensor
110	AGT B6 Busbar (-)	Temperature at busbar (-) of the B6 bridge too high/Sensor error: Short circuit on temperature sensor
111	AGT B6 Busbar (+)	Temperature at busbar (+) of the B6 bridge too high/Sensor error: Short circuit on temperature sensor
126	Fuel temperature	Fuel temperature too high/Sensor error Short circuit on temperature sensor
130	CAN communication interrupted	The panel has lost contact with the control system
131	CAN communication interrupted	The control system has lost contact with the panel
132	Service interval	Service due
133	BUS Module lost (3ph measurement)	Communication with the 3-ph Module interrupted
134	BUS Module lost (DC measurement)	Communication with the AGT Module interrupted
135	Synchronisation error	Problem with synchronisation of the output voltages of generators switched in parallel.
136	External motor controller communication	Communication with the external motor controller (ECU) has been interrupted
137	Air filter	Air filter has generated an error message
138	Diagnostic message (ECU)	Control device of the diesel engine has transmitted a diagnostic warning

No.	Description	Basic
139	Synchronisation module communication	Communication with the synchronisation module has been interrupted
140	Load distribution	Load balancing error
141	Synchronisation deactivated	Synchronisation module deactivated
142	Error message from engine control unit	The diesel engine control unit has generated a Red Stop Lamp Error
148	Rotary field error	The phases are connected in the incorrect sequence
149	Fuel level sensor error	Communication with the fuel level sensor has been interrupted
151	"Watchdog", control system restart	Control system is restarted after a malfunction
152	Temperature Inverter L1	Temperature of L1 of the inverter above upper limit
153	Temperature Inverter L2	Temperature of L2 of the inverter above upper limit
154	Temperature Inverter L3	Temperature of L3 of the inverter above upper limit
155	Temperature Inverter DC intermediate circuit	Temperature of the DC intermediate circuit of the inverter is above upper limit
157	Inverter communication	Communication with the inverter has been interrupted
163	Inverter DC intermediate circuit load	DC intermediate circuit current is above upper limit
164	Inverter DC intermediate circuit voltage	Inverter DC intermediate circuit voltage too high
167	No rev analysis/Monitoring	Simulation of the engine speed for start-up without inverter
245	Factory setting changed	User input in Factory menu
251	Parameter changed in Admin Level	User input in Admin menu


2.6.2.2 Description of the symbols

Fig. 2.6-1: Description of the symbols

Symbol	Description		Symbol	Description	
	WARNING			Current	Generator output
	Error shutdown			Frequency	Generator output
	Faults	No contact		Voltage	Generator output
	Broken	Short circuit		(%)/Load	
	OK			Generator runs	
	AC Voltage			Generator off	
	Run-up phase/Override	Generator start-up		Temperature	
	Standby			Engine	
	Automatic start-up.			Exhaust system	
	Starter battery			Winding	

Symbol	Description		Symbol	Description	
	Operating hours			Preheating	
	Oil pressure			Speed/RPM	
	Self test			Tank gauge %	
	Apparent power			Starter turns	

Example:



Error73: Error shutdown due to winding temperature

2.7 Accessories:

FP Bus Cable (15 m): 34.02.02.131H

Fig. 2.7-1: FP Bus Cable (15 m): 34.02.02.131H



Terminating resistor:34.02.02.133H


Fig. 2.7-2: Terminating resistor:34.02.02.133H



Adapter Frame: 31.03.20.263H


xControl CP-G in a Generator Control (P6+) section


Fig. 2.7-3: Adapter Frame: 31.03.20.263H



2.7.1 Dimensional drawing

Fig. 2.7.1-1: CP-G



 Fischer Panda Otto-Hahn-Str. 32-34 D-33104 Paderborn Tel.: (05254) 9202-0 Fax (05254) 9202-92 Info@fischerpanda.de www.fischerpanda.de		Maßstab: Gewicht: Material: Halbzeug: Artikel-Nr.: Inhalt:	Panel iControl 2 / xControl Ausstattung und Befestigungspunkte
Bearb. 27.06.11 Entw. GR	Datum Name	Zeichnungs-Nr.: Blatt:	6993e01 1 1
Allgemeine Toleranzen nach DIN ISO 2768-mK Schutzvermerk nach DIN 34 beachten!		Ersatz durch:	
Zust.	Anmerkungen	Datum	Name